



Contains biocidal products (preservatives) contains reaction mass of: 5-chloro-2-methyl-4-isothiazolin-3-one and 2-methyl-2H-isothiazol-3-one (3:1); 1,2-benzisothiazol-3(2H)-one. May produce an allergic reaction. P102: Keep out of reach of children. P271: Use only outdoors or in a well-ventilated area. P501: Dispose of contents/container to a waste collection center (contact the local authority). EU limit value for this product (cat. A/el): 130 g/L (2010). This product contains max 25 g/L VOC. Do not allow to freeze.

This product should be used in accordance with the manufacturer's instructions. Recommendations are for guidance only since conditions of use are completely beyond our control. For technical or practical information on this or other Liberon products please contact Liberon Technical Services on 01797 367555.

Liberon Limited,  
Mountfield Industrial  
Estate,  
New Romney,  
Kent TN28 8XU  
+44 (0) 1797 367555  
[www.liberon.co.uk](http://www.liberon.co.uk)

Head Office-V33 Group  
Rue de la Croix Bernard  
BP 1  
F-39210 DOMBLANS  
cedex  
Tél. (+33) 3 84 35 00 33  
[www.groupev33.com](http://www.groupev33.com)



#### PREPARATION

Sand the wood if required and remove all previous finishes. Ensure the surface is clean, dry and free from dust. If you want to colour the wood, you can apply Liberon Palette Wood Dye to the timber before varnishing. Alternatively Liberon Palette Wood Dye may be added to the varnish to create unique colour tones. Liberon Palette Wood Dye is available in a range of wood shades.

#### APPLICATION

Shake / stir well before use. Apply a reasonable coat of varnish evenly using a paint brush or short hair roller and allow to dry for a minimum of 2 hours before applying further coats. We recommend a minimum of 3 coats are applied, sanding lightly between coats if required. More coats may be required for items which are in heavy use. Allow the final coat of varnish a minimum of 24 hours drying time before use.

**Important:** Always test product on a spare surface or inconspicuous area for colour, compatibility and end result.

Remove as much of the product as possible from the tools after use. Do not dispose of residues and washing water/solvents in the sink, toilet, sewer, bin, etc., in order to avoid discharge into the environment.

#### CLEANING AND MAINTENANCE

Wipe any spills immediately. For general maintenance wipe over with a damp cloth using a mild detergent if required. If the surface shows signs of wear, re-apply a coat of varnish.

#### PRECAUTIONS

Allow all wood dyes to dry for a minimum of 8 hours before applying Natural Finish Interior Varnish. Care must be taken on the application of the first coat of Natural Finish Interior Varnish when being used over Liberon Palette Wood Dye. Keep brush strokes to a minimum as over-brushing may lift out the colour. The varnish may raise the grain on some hard woods. Do not exceed a 20% dilution of Natural Finish Interior Varnish with Liberon Palette Wood Dye. Natural Finish Interior Varnish is not suitable for applying over an oil-based finish.

#### LIBERON ADVICE

In order to avoid bubbles forming on the surface of the varnish when using a roller, we recommend the use of a short hair roller and that work is not carried out at temperatures above 25°C. Apply successive coats in a crisscross format (right to left then left to right) applying the final coat in the direction of the grain.

# 1L

Made in  
the EU

Min.  
2h

Drying Time:  
Recoat

24h

Drying Time:  
Fully dry



Tools:  
Brush or roller



Tools cleaning:  
Water



1L = 10-12 sqm

5063886 - Made in the EU